



FB 430 / FB 450 / FB 500 / FB 510

USER MANUAL IN ORIGINAL



USE

SWEPAC FB430 / FB 450 / FB500 / FB 510

are used to pack ballast under foundations, in connection with road building, in trenches, etc. On account of the forward/reverse function, the machine is very suitable for packing in tight spaces and as a complement to larger packing equipment. The infinitely variable speed control makes it possible to move with great precision and to pack without moving.

CONTENTS

USE	3
SAFETY INSTRUCTIONS	4
STANDARDS	4
SIGNS	5
TECNICAL DATA.....	6
METHOD OF OPERATION	6
TECHNICAL DESCRIPTION.....	7
DAILY CHECKS.....	8; 9
BEFORE STARTING	10
STARTING, Yanmar	10
STOPPING	10
BEFORE STARTING.....	11
STARTING, Hatz	11
STOPPING.....	11
OPERATING INSTRUCTIONS	12
TRANSPORTATION	12
BELT TENSION / REPLACEMENT OF THE BELT.....	13; 14
ERROR DIAGNOSTICS FB450 and FB510.....	15; 16; 17
MAINTENANCE SCHEDULE FB450 / FB510.....	17
MEASURING AND ADJUSTMENT THE HYDRAULIC PRESSURE FB 450 / FB 510.....	18
HYDRAULIC DIAGRAMM 450 / FB 510.....	19
MEASURING AND ADJUSTMENT THE HYDRAULIC PRESSURE FB 430 / FB 500.....	20
HYDRAULIC DIAGRAMM 430 / FB 500.....	20
WIRING DIAGRAM FB430 / FB450 / FB 500 / FB510.....	21; 22; 23; 24; 25
COMPACTION INDICATOR (SCI).....	26
EC-DECLARATION OF CONFORMITY.....	27

SAFETY INSTRUCTIONS

- Before using the machine, the operator must be informed of the manufacturer’s safety instructions and instructions for use.
- The machine may only be used outdoors.
- The machine may not be used if protection and safety devices are not present or not working.
- The operator may not leave the machine unattended when the engine is on. When the vibrator is connected, the operator must be able to control the movement of the machine using the control handle and the start/stop controls. The machine may be operated only by a trained operator.
- During maintenance work or other interventions in the machine, the engine must always be off.
- Switch the engine off before adding fuel. Avoid fuel spillage and immediately wipe off any spilled fuel. Add fuel only in well ventilated areas.
- Avoid touching hot engine parts, for example the silencer.
- Before lifting the machine, check that the lifting device and its mounting are not damaged and that the rubber dampers on the base plate are undamaged and tightened.
- During transportation and storage, the fuel tank should be empty and the fuel cock switched off.
- When the machine is parked, ensure that it cannot tip over. The machine may not incline more than 20°.
- The operator must use ear protectors when working with the machine.
- The operator must ensure that no unauthorised persons are in the immediate vicinity of the machine.
- Always wear personal protective equipment as heavy, non-slip shoes, ear protectors and approved eye protection.
- The machine may not be used in environments in with potential fire or explosion danger.
- Never use the machine if you are tired or have consumed alcohol or are under medication that could affect your vision, your discretion or your coordination ability.
- Never use a machine in any way changed from the original design.

STANDARDS

Noise

Measurement in accordance with the standard EN 500-4 Rev. 1:1998, Annex C:

Measurement uncertainty ± 0.5 dB (A) in 95% of the measurements.

In accordance with the conditions in Directive 2000/14/EC, Annex VI, the following values are reported:

	FB 430	FB 450	FB 500	FB 510
Sound pressure level at the operator’s ears, L _{pA}	93 dB (A)	93 dB (A)	93 dB (A)	93 dB (A)
Permitted sound power level, L _{WA}	108 dB (A)	108 dB (A)	108 dB (A)	108 dB (A)
Guaranteed sound power level, L _{WA}	108 dB (A)	108 dB (A)	108 dB (A)	108 dB (A)

As the sound pressure level at the operator’s ears exceeds 80 dB (A), ear protectors must be used during operation!

Hand/arm vibrations

The vibration acceleration was measured in accordance with the ISO 5349 standard during operation on a surface of macadam. The measurement values were translated into the maximum daily exposure time for regular usage. For additional information about vibrations, please confer the regulation AFS 2005:15 from the Swedish Work Environment Authority, effective July 1st 2005.

Measurement uncertainty ± 0.3 m/s² in 95% of the measurements


	FB 430	FB 450	FB 500	FB 510
Hand/arm vibrations, m/s ²	2,9	2,6	2,9	2,6
The maximum daily exposure time	5,95 h	7,4 h	5,95 h	7,4 h

Exhaust Emissions

The FB 430 / FB 450 / FB 500 / FB 510 meets the requirements for exhaust emissions in accordance with US-EPA stage 2.

SIGNS

Warning Signs



Before use, carefully read the manual and its safety instructions so that you can handle the machine safely. Ensure that the manual is always accessible.



Engine, silencer: to avoid burns or discomfort, do not touch hot engine parts when the engine is on or when the machine has recently been used.




Only FB 430 and FB 500

Belt drive: Keep hands, tools and other objects away from the belt drive when the machine is on to avoid injury and damage. See the safety instructions in the manual.



As the sound pressure level at the operator's ears exceeds 80 dB (A), ear protectors must be used when working with the machine to prevent hearing damage.

Machine Signs



1. Manufacturer
2. Place, country of manufacture.
3. CE mark.
4. Model name.
5. Year of manufacture.
6. Max. engine power.
7. Max. weight.
8. Serial number.
9. Machine type

TECHNICAL DATA

FB 430

Net weight.....430 kg
 Base plate, w x l.....700 x 1080 mm
 Speed.....approximately 25 m/min
 Permitted inclination20°
 Centrifugal force66,000 N
 Vibration frequency70 Hz
 Drive engine.....Yanmar L 100N
 Engine power7 kW
 Engine RPM.....3000 RPM
 Fuel tank volume.....5.5 liter
 Fuel type.....Diesel
 Hydraulic oil quantity.....1,6 liter
 Battery capacity40 Ah
 Generator power.....180 W (15 A)

FB 450

Net weight.....445 kg
 Base plate, w x l.....700 x 1080 mm
 Speed.....approximately 25 m/min
 Permitted inclination20°
 Centrifugal force60,000 N
 Vibration frequency72 Hz
 Drive engine.....Yanmar L 100N
 Engine power7 kW
 Engine RPM.....3000 RPM
 Fuel tank volume.....5.5 liter
 Fuel type.....Diesel
 Hydraulic oil quantity.....12 liter
 Battery capacity40 Ah
 Generator power.....180 W (15 A)

FB 500

Net weight.....490 kg
 Base plate, w x l.....700 x 1080 mm
 Speed.....approximately 25 m/min
 Permitted inclination20°
 Centrifugal force66,000 N
 Vibration frequency72 Hz
 Drive engine.....Hatz 1D50Z
 Engine power7.5 kW
 Engine RPM.....3000 RPM
 Fuel tank volume.....5.5 liter
 Fuel type.....Diesel
 Hydraulic oil quantity.....1,6 liter
 Battery capacity40 Ah
 Generator power.....180 W (15 A)

FB 510

Net weight.....500 kg
 Base plate, w x l.....700 x 1080 mm
 Speed.....approximately 25 m/min
 Permitted inclination20°
 Centrifugal force66,000 N
 Vibration frequency72 Hz
 Drive engine.....Hatz 1D50Z
 Engine power7.5 kW
 Engine RPM.....3000 RPM
 Fuel tank volume.....5.5 liter
 Fuel type.....Diesel
 Hydraulic oil quantity.....12 liter
 Battery capacity40 Ah
 Generator power.....180 W (15 A)

METHOD OF OPERATION FB 450 / FB 510

The machine consists of a base plate with a vibration element and an upper part cushioned from the base plate. The cushioning between the base plate and the upper part consists of four rubber dampers. The upper part, on which the drive engine is mounted, is also designed as a hydraulic oil tank. The control handle is placed on the upper part and cushioned with rubber dampers. The vibration element is driven and the direction of travel is changed by means of hydraulics. The hydraulic pump, mounted on the diesel engine, supplies a hydraulic motor on the vibration element with an oil flow. The vibration element consist of two shafts on roller bearings with bias weights that are connected to gear wheels that rotate in opposite directions. One gear wheel can rotate on its shaft by means of a hydraulic cylinder. This changes the mutual phase positions of the eccentric weights and the direction of travel of the machine, and the speed is changed infinitely variably. The engine is well protected against damage in connection with use and transportation by a sturdy protective frame with a protective panel.

METHOD OF OPERATION FB 430 / FB 500


The machine consists of a base plate with a vibration element and an upper part cushioned from the base plate. The cushioning between the base plate and the upper part consists of rubber dampers. The power is transmitted from the engine to the vibration element via a V-belt which can be adjusted with a belt tensioner. The engine V-belt pulley is fitted with an integrated centrifugal clutch, which allows the engine to be started and run idle without the vibrator being connected. The engine is well protected against damage in connection with use and transportation by a sturdy protective frame with a protective panel.

FUEL and OIL RECOMMENDATIONS	
Fuel	Diesel
Engine oil.....	SAE10W-30
Oil quantity, crankcase.....	1,5 liter
Engine oil change diesel engine: first oil change after 50 hours then every 200 hours of operation. Replace the filter when you change oil.	
Hydraulic oil type / quantity FB450 / FB510.....	HydraWay BIO SE 32-68.....12 liter
Hydraulic oil type / quantity FB430 / FB500.....	HydraWay BIO SE 32-68.....1,6 liter
Replace hydraulic oil filter.....	after 3 years
Oil type/quantity, vibration unit.....	SAE10W-30.....0,5 liter


TECHNICAL DESCRIPTION

FB 450 / FB 500 / FB 510

Left side view



Right side view



Left side view

1. Cover
2. Lifting eye
3. Control panel
4. Hydraulic tank
5. Control handle
6. Forward/reverse control
7. Throttle
8. Base plate
9. Rubber damper
10. Battery
11. Vibration element
12. Protective lock, left side
- 13A. Hydraulic pump FB450 / FB510
- 13B. Centrifugal clutch FB430 / FB500
- 13C. Belt guard FB430 / FB500
14. Engine

Right side view

15. Battery cover
16. Hydraulic oil filter FB450 / FB510
17. Throttle lever FB450 / FB510
18. Air filter
19. Protective frame
20. Protective lock, left side
21. Protective list
22. Hydraulic oil cooler FB450 / FB510
23. Transport locking device
24. Handle heating switch FB450 / FB510
25. Switch start and stop the vibrator

DAILY CHECKS

Fuel Check


Check that there is fuel in the tank. Top up if necessary.

Engine Oil Level Check


Check the oil level in the crankcase every day. Turn off the engine. The machine is on a level surface.

FB430 / FB 450: The oil must reach the edge of the filling hole.

FB 500 / FB 510: The oil must reach up to the "MAX" marking.



FB 430 / FB 450



FB 500 / FB 510


Oil/Fuel Leakage

Check every day that the engine is not leaking oil or fuel. If a leak is discovered, the machine may not be operated until the fault has been remedied.

Air Filter Check

The air filter must be checked at least once every working week. When working in dusty conditions, check daily.

FB 430 / FB 450




1. Filter plate
2. Foam plastic element
3. Paper element
4. Filter cover
5. Cyclone filter collector

Cleaning

1. Remove the foam plastic element and the paper element and check that they are undamaged. Replace damaged parts.
2. Wash the foam plastic element in liquid with a high flashpoint and let it dry properly. Dip in engine oil and squeeze dry.
3. Strike the paper element against a hard object a few times to loosen any dirt.
4. Check that the filter plate is clean. Clear the cyclone filter collector.

FB 500 / FB 510



1. Indicator
2. Filter plate
3. Filter
4. Air intake with cyclone
5. Filter cover

Cleaning

With the engine at full RPM, press in the indicator (1) for the air filter. If it remains depressed, clean the filter as described below. This may need to be done several times a day in dusty conditions.


1. Loosen the wing screw in the filter cap (5). Check that the dust outlet (4) is not clogged. Clean it if necessary.
2. Loosen the filter (3) and blow it clean with dry compressed air, max. 5 bar, from the inside until no more dust comes out. Replace a damaged filter.
3. Check that the filter plate (2) in the filter housing is clean.

Hydraulic Oil Level Check FB 450 / FB 510

Check every day that the hydraulic connections do not leak or wear during operation. The oil level in the tank must be according the picture below.

Fill up hydraulic oil as described below.


Remove the battery cover. Remove the tank cover (1). Remove the filter (2). Fill up hydraulic oil and reassemble filter and cover. The cover must be well tightened when reassembling.



Hydraulic Oil cooler FB 450 / FB 510

The machine is equipped with a hydraulic oil cooler. The cooler start working when the hydraulic oil reach a temperature +50 °C. Afterwards subsequently switch to and from the coolers as necessary. After shutting off the machine, the cooling fan run for a short time, which is normal.

Note! If the indicator light for hydraulic temperature (see the panel picture for each machine) lights red it indicates that the hydraulic oil temperature is to heat. Continue driving the machine means worse compaction capability. Stop and check the hydraulic oil cooler.



Termostater

- 1. Termostat for the hydraulic oil cooler fan
- 2. Termostat for warning light high oil temperature


V-belt Drive FB 430 / FB 500

Check the tension and condition of the V-belt regularly. Replace a damaged V-belt with the new type according to the table below

Machine type	V-belt type
FB 430	XPB 1322
FB 500	XPB 1242


Hydraulic Oil Level Check FB 430 / FB 500

Check every day that the hydraulic connections do not leak or wear during operation. Check the oil level with the dipstick on the top of the tank. The level must be between “MIN” and “MAX”. Fill up when required.



Vibration Element

Check regularly that there is no oil leak. Seal any leaks. **Note!** Machines must never be operated if a leak is suspected. **Note!** The oil level in the vibration element is 0,5 liter.




- 1. Drain and refill hole


Rubber Damper

Check the condition of the rubber dampers regularly. Replace damaged dampers.


FB 430 / FB 450




Yanmar fuel cock



Yanmar decompression handle



Vibration power switch and handle heating



FB 450 instrument panel with throttle lever

1. Engine power switch
2. Control lamps for charging, oil pressure and hydraulic oil temperature
3. Full throttle position
4. Stop mode
5. Throttle

BEFORE STARTING

See Daily Checks on page 8.

STARTING only FB450

Note! The vibration power switch on the handle must be in the position “vibration off” (red/green marking). Otherwise the machine cannot be started.

Open the fuel cock.

Switch the throttle lever (5) to the full RPM position (3). Start the engine with the power switch (1). Place the knob in the central position and check that the charging and oil pressure lamps (2) light up. With the power switch in this position the buzzer starts to sound. Then press the power switch down (Start marking).

Note! Never run the starter motor for longer than 10 seconds at a time. If the engine does not start, wait 15 seconds before trying to start it again.

In very cold weather or if the battery capacity is low for a different reason, starting can be facilitated using the decompression handle in connection with the valve housing. Press the lever down and hold it down until the flywheel has reached its maximum RPM. Run the engine warm for around 5 minutes.

STOPPING FB450

Turn off the vibration. Switch the throttle lever (5) to idle and let the engine run for a few minutes.

Press the engine power switch (1) upwards (O marking).

Stop the engine by moving the throttle lever to the stop position (4)

At the End of the Day

Close the fuel cock.

STOPPING FB430



Press the engine power switch (1) upwards (O marking).

Stop the engine by moving the throttle lever to the stop position (4)

At the End of the Day


Close the fuel cock.

FB 430 Instrument panel




SWEPAC


FB 500 / FB 510



Hatz decompression handle



Vibration power switch and handle heating



FB 510 instrument panel with;

1. Control lamps for the engine, charging, oil pressure and hydraulic oil temperature
2. Starter key
3. Full throttle position
4. Stop mode
5. Throttle

BEFORE STARTING

See Daily Checks on page 8.

STARTING only FB510

Note! The vibration power switch on the handle must be in the position “vibration off” (red/green marking). Otherwise the machine cannot be started.

Switch the throttle lever (5) to the full RPM position (3). Insert the starter key (2) in position 0 and turn to the position 1 and check that the charging and oil pressure lamps (1) light up. With the starter key in this position 1 the buzzer starts to sound. Turn the starter key to the position 2. Release the key as soon as the engine starts. It returns to position 1 and will remain in that position during operation. Charging and oil pressure light goes off immediately after the start. Engine light (1) lights green while the engine is running.

Note! Never run the starter motor for longer than 10 seconds at a time. If the engine does not start, wait 15 seconds before trying to start it again.

In very cold weather or if the battery capacity is low for a different reason, starting can be facilitated using the decompression handle in connection with the valve housing. Press the lever down and hold it down until the flywheel has reached its maximum RPM. Run the engine warm for around 5 minutes.

STOPPING FB510

Turn off the vibration. Switch the throttle lever (5) to idle and let the engine run for a few minutes.

Turn the starter key to the position 0.



Stop the engine by moving the throttle lever to the stop position (4)

STOPPING FB500

Turn the starter key to the position 0.

Stop the engine by moving the throttle lever to the stop position (4)


FB 500 Instrument panel



OPERATING INSTRUCTIONS

The vibrator is started and stopped with the power switch on the handle.


When the control hoop on the handle is moved backwards, the machine reverses and when the hoop is moved forwards, the machine moves forwards. The speed is controlled by how long the control hoop is activated.



The machine is only designed to be used outdoors. Work with the machine in daylight or other adequate lighting. Ballast must be wetted or naturally damp. All other use is discouraged.

Note! When moving up a slope, the machine should be reversed.

The machine may not incline more than 20° when in use or parked.




Handle Heating

For increased comfort, the machine has an electrically heated handle. The handle heating is activated with the power switch on the handle and can only be used when the vibrator is connected, which prevents the heating coil from discharging the battery when the machine is not being used.


TRANSPORTATION

The machine is fitted with a lift eye that can be placed on the hood when not in use.

NOTE! Use only safety frame lifting point (1) to lift the machine.




Check before lifting that the lifting eye and its mounting on the machine are undamaged. Check also that the base plate's rubber dampers are undamaged and firmly attached. For transportation by vehicle, the handle must be folded forwards and locked with the transport locking device. The machine must then be secured with, for example, approved straps. Note! Secure it by the base plate and not the rubber-cushioned upper part.




Transport locking


Secure the machine with straps according to illustration during transportation



Belt tension / replacement of belt refers to FB430 och FB500



Loosen the belt cover



Start by loosening the three stop screws, both when releasing and tensioning the belt (as shown in Fig.)




Placing the hook wrench



1. Release the hook wrench from its storage position.
2. Attach the hook wrench to the motor, using the spacer sleeve between the motor and the hook wrench.
3. Turn the external part of the centrifugal clutch counter clockwise to release the belt tension as shown above.




1. **Attach the hook wrench to the motor, using the spacer sleeve between the motor and the hook wrench.**
2. **Turn the external part of the centrifugal clutch clockwise to release the belt tension as shown in Fig. above.**



To change the belt, follow the illustration and turn the external part of the centrifugal clutch counter clockwise.

Apply some pressure with the spanner as shown in Fig. and turn the external part of the centrifugal clutch clockwise to tighten the belt.



The centrifugal clutch is separable

Reassemble in reverse order.

Note! Don't forget to tighten the three stop screws.

ERROR DIAGNOSTICS FB450 and FB510

PROBLEM	REASON	REMEDY / SOLUTION
The engine won't start	The circuit breaker is in position; "vibration on"	Turn off the circuit breaker
	Wrong fuel or water type in the tank. Even contamination.	Clean the fuel system and fill it with the correct type of fuel
	Battery poor, low voltage. Also check if the charge regulator is charging at the correct value	Charge or replace the battery. In case of charging failure, check cables or replace the regulator
	Ignition lock failure (FB510) Starter switch contact failure (FB450)	Check if power exists to the starter motor when turning to start the engine. Replace the ignition lock or starter switch if necessary
	Electrical fault in starter box.	Open the box and check the cables and connections. Remedy fault.
	The starter engine isn't working	Check the cables and connections or replace the starter engine
	Fuel pump broken	Check pressure and flow
	Other engine failures	See the engine manufacturer's repair manual
Engine starts, but runs poorly	Wrong fuel or water type in the tank. Even contamination.	Clean the fuel system and fill it with the correct type of fuel
	Air filter clogged	Replace the air filter
	Fuel filter clogged	Replace the fuel filter
	Air intake in fuel tubes due to cracks	Replace broken fuel tubes
	Other engine failures	See the engine manufacturer's repair manual
The ground vibrator motor starts but the vibrations are completely absent	Failure of the solenoid valve coil, its cable connection or wiring	Try turning the solenoid to another position, or check the function of the cable connection
	Circuit breaker for "vibrations on" is broken	Replace the circuit breaker
	Cable rupture or loose contact in the electrical system	Find the source of the failure and fix it
	No power supply to the circuit breaker	Check where the interruption is located further back in the electric system

	Solenoid valve stuck	Check the oil pressure in the high-pressure system if it reacts to vibrations on
	Broken hydraulic tube, oil does not reach, or with too low pressure	Replace broken tubes
	Failure in hydraulic engine	Check function and tightness. Replace broken parts
The ground vibrator does not move backwards as it should when the lever moves backwards. Failure in the low pressure system's hydraulic oil.	The O-rings in the switch cylinder are worn or broken and hydraulic oil has leaked into the vibration element	Disassemble the switch cylinder and replace the O-rings. Drain the oil in the element and refill new oil as recommended
	The bearing of the control shaft under the piston is worn or has failed. Dismantle the cylinder and feel if it is possible to rotate the piston	Replace the two ball bearings inside the piston Check the surface of the cylinder for scratches. Replace the cylinder if necessary
	Scratches on switch cylinder or piston	Check the cylinder or the piston. Replace if necessary
	Handle valve failure	Check oil pressure first and replace valve if necessary
	Mechanical failure inside the vibration element	Open the vibration element and remedy failure
The hydraulic oil gets too hot. The light in the panel indicates an overheated system.	Cooling fan not working	Check electrical connections and replace cooling fan if necessary. The relay that starts the fan when the temperature is too high is broken. Replace the relay.
	Too little oil in the hydraulic tank	Refill after a leakage check has been carried out
	The thermostat is not working. There are 2 parts. One which starts the fan at 60 degrees, and one that turns on the warning light on the control panel at 80 degrees	Replace broken thermostat valve
The compact meter isn't working. Lights do not turn on	Interruption in cables between sensor and instrument panel	Remedy cable ruptures
	The sensor isn't working	Check the wiring. If it is intact, replace the sensor with the cable attached to the vibration element

	The panel isn't working	Replace the panel
--	-------------------------	-------------------

MAINTENANCE SCHEDULE FB450 /FB510

Remedy	DAILY	100 HOURS	200 HOURS	200 HOURS	YEARLY	AFTER 3 YEARS
Fuel level	X					
Fuel leakage	X					
Oil level in engine	X					
Air filter	X					
Battery	X					
Lifting hook / frame	X					
Hydraulic system leakage / level	X					
Hydraulic oil level	X					
Rubber dampers		X				
Functional control's electrical system					X	
Functional control's hydraulic system		X				
Oil change of engine	First change after 50 hoursr		X			
Replace fuel filter					X	
Check tightening of visible screws and nuts		X				
Drain the fuel tank and clean the glass cup (510)					X	
Control/adjust valve clearance					X	
Checking/replacing the stick in the vibration element						X
Checking/replacing the O-ring on the switch piston					X If necessary	
Replace hydraulic oil filter					X Or every 2nd year	
Replace hydraulic oil						X

Note! The proposed interval time is an indicative value for a normal use. Approx. 220–250 hours/year. Applies to the following models FB450 and FB510

Dok:101498E-GB 2247

MEASUREMENT AND ADJUSTMENT OF HYDRAULIC OIL PRESSURE FB450 / FB510

A clear picture of the hydraulic system's state or an indication of the cause of malfunction is obtained by simultaneously measuring the system pressure, the drive motor speed and vibration frequency. The soil compactor shall be in operation and maintain normal operating temperature. Hydraulic oil temperature 50-70 ° C.

The hydraulic system's maximum pressure is preset upon delivery. Default pressure is 200 bar and can be measured in the starting moment when the oil in the hydraulic system is cold.

When the soil compactor has reached normal operating temperature, the pressure must be 30-50 bar lower than the system's maximum pressure.


The pressure increases proportionally with increasing load, eg if the soil compactor is run at low speed or even standing still during operation. When maximum pressure is reached, vibration speed is reduced.

Measurement of drive motor speed and vibration frequency is performed with a strobe with graduated scale. The hydraulic pressure is measured with a pressure gauge with connection for gauge ports on the valve block, see picture. The hydraulic pressure for the conversion should be between 20-22 bar and is measured with a pressure gauge with connection for gauge ports on the distribution block, see picture. Strobe light and gauge can be ordered at SWEpac.


Engine speed3000 rpm loaded Yanmar / 2900 rpm loaded Hatz

Vibration frequency at hydraulic oil temp. ca. 50 ° C 70-72 Hz; 4200-4320 rpm

Normal running pressure hydraulic oil temp. ca. 50 ° C 150-170 bar



Hydraulic diagram FB450 / FB510




- 1) Hydraulic pump 6.14 cc 3000 rpm (Yanmar) 6.45 cc 2900 rpm (Hatz)
- 2) Pressure relief valve max 200 Bar
- 3) Solenoid valve vibration On / Off
- 4) Hydraulic Motor 4.09 4300rpm
- 5) Hydraulic cylinder Front / Back
- 6) Measuring point
- 7) Return oil filter
- 8) Hydraulic pump conversion 0.75 cc 4300 rpm
- 9) Valve block conversion

Measurement of the conversion hydraulic oil pressure FB430 / FB500


In order to measure hydraulic oil pressure for the conversion, the cover plate on the rear of the handle must be removed.

The hydraulic pressure for the conversion should be between 20-22 bar and is measured with a pressure gauge with connection for gauge ports on the valve block, see picture. The measuring point is plugged from the factory. In order to measure the hydraulic oil pressure for the conversion, the plug must be unscrewed and a measuring point put there instead. Pressure gauge and measuring point (101027 measuring point) can be ordered from SWEPAC.




Hydraulic diagram FB430 / FB500

VIBRATIONS UNIT




- 1) Hydraulic pump conversion
- 2) Pressure relief valve 20 Bar
- 3) Hydraulic cylinder Front / Back
- 4) Manually operated valve block conversion


WIRING DIAGRAM FB 430




WIRING DIAGRAM FB 450




WIRING DIAGRAM FB 500



WIRING DIAGRAM FB 510



WIRING DIAGRAM OIL COOLER FB 510




ACCESSORIES

Swepac Compaction Indicator (SCI)

SCI consists of an accelerometer sensor mounted on the right side of the vibration element, and a display unit provided with LEDs that light up as the compaction progresses. The sensor and the display are connected with a cable. The display is also powered by a separate cable.

The Principle:

The base plate motion characteristics vary with increasing or decreasing soil compaction. The sensor continuously measures the variations in the base plate movement. The data from this is analyzed in the processor, which in turn sends signals to the display to visualize this with the lights.



When starting:

When starting with the ignition key, the yellow LEDs 1, 3, 5, 7 will flash at first and thereafter the LEDs 2, 4, 6, 8 will flash.

The diodes remain lit until communication with the sensor is operating. This normally takes a second. If the power supply is interrupted or communication stops for more than 20 seconds, the flashing LED pattern returns until the communication works again. Thereafter, all the LEDs will be turned off and the indicator is ready for operation.

After starting the machine or after onset of vibrations (FB450 and FB510), it will take 2-3 seconds before the indicator starts to record the movements of the base plate. The reason is that the sensor does not start measuring until the vibrator generates the correct frequency on the base plate. The display will not indicate anything if the speed of the engine is reduced since the vibrator then is slower and the base plate does not reach the right frequency.

No calibration of the indicator is required when starting the machine.

During use:

When operating, the LED lights will illuminate from left to right. The number of lights that are lit during operation is dependent on soil quality and characteristics. When the number of lit lights do not increase, the ground will not be compacted further at other crossings. It therefore means that all lamps will not necessarily be lit during the compaction work.

The lights indicate the surface's compression status during the work. If no more lights are lit, the maximum compaction of the substrate is achieved. Swepac Compaction Indicator is no substitute for the conventional assay of the degree of compaction but is used to provide the operator with useful information such as finding areas that are not compacted or to avoid overcompacting with the risk of damage to the machine.



EC-declaration of conformity

Manufacturer

**Swepac AB
Bergvägen 7
34132 Ljungby**

1. Category: Vibratory plate

2. Type: FB430.....7kW
FB450.....7kW
FB500.....7,5kW
FB510.....7,5kW

3. Engine power: FB430.....7kW
FB450.....7kW
FB500.....7,5kW
FB510.....7,5kW

The product complies with the following directives:

2006 / 42 / EG

2000 / 14 / EG

2004 / 108 / EG

EN 500-1

EN 500-4

Technical documentation held by:

Swepac AB, Bergvägen 7 SE-34132 Ljungby
Tomas Johansson / Product Engineer